

# The ReadMe of Window WDDM Driver

## O.S. Support:

- Windows Server 2012 R2 (WHQL)
- Windows Server 2016 (WHQL)
- Windows Server 2019 (WHQL)
- Windows Server 2022 (WHQL)

## Driver Installation Guide:

### INF Installation:

- Windows Server 2012 R2
  - Select INF file in Win2012 R2
- Windows Server 2016
  - Select INF file in Win2016
- Windows Server 2019
  - Select INF file in Win2019
- Windows Server 2022
  - Select INF file in Win2022

## FAQ:

- Show “Code 52” on Windows Server with non-WHQL driver
  - Disable Secure Boot
  - Reference Link:

<https://techcommunity.microsoft.com/t5/windows-hardware-certification/driver-signingchanges-in-windows-10-version-1607/ba-p/364894>

## Contact:

E-mail: [aspeed\\_vga\\_support@aspeedtech.com](mailto:aspeed_vga_support@aspeedtech.com)

ASPEED Technology Inc.